

Common Setup for Design Shop Accelerator Editor Hot keys

Actual Size	1	Next Element	Tab or arrow
Auto Compute Splice Lines	F4	Previous Element	Shift + Tab
Break Splice Lines	F8	Previous Insert Tool	Spacebar
Column 1 (input A)	Shift + Q	Properties	P
Column 2 (input B)	Q	Ruler	R
Single Line (input C)	Ctrl + Q	Show All	Shift + S
Center Design	Ctrl +F1	Show Graphics	D
Clear Splice Lines	F3	Show Stitches 3-D	T
Complex Fill	Shift + F	Show/Hide Stitches	S
Custom Selection	C	Trim	\
Deselect All	X	Walk Normal	W
Edit Mode	H or O	Walk Bean	Shift + W
Expanded Editing Mode	E	Zoom In	Z
Fit Selection	F	Zoom Out	Shift + Z
Fit Window	0 (zero)	Zoom Previous	V
Graphical Zoom	B		
Hide Graphics	Shift + D		
Insert Splice Line	F2		
Insert Start & Stop Points	F9		
Lettering	A		
Manual Stitch	M		